

WM-112

Serial to Ethernet Module

User Manual

Version 1.0

Infosystem Technology Corporation, Ltd.

Index

1. Disclaimers	1.
A. Warranty	2.
B. Trademark	2.
2. Product Information	3.
A. Introduction	3.
B. Features	4.
C. Applications	5.
3. Exterior	6.
A. Top View	6.
B. PIN Assignments	6.
C. PIN Descriptions	7.
4. Software Installation	8.
A. Install	8.
- Step 1: Insert the CD and click the button	8.
- Step 2: Click the Link of the Page	9.
- Step 3: Press Next to Continue	10.
- Step 4: Decide the Application Directory	11.
- Step 5: Create the Directory if not existent	12.
- Step 6: Create Program's Shortcut	13.
- Step 7: Decide if Desktop icon needed	14.
- Step 8: Press Install to start installation	15.
- Step 9: Process Installations	16.
- Step 10: Finish Installation	18.
B. Uninstall	18.
- Step 1: Uninstall Ethernet Converter	18.
- Step 2: Processing	19.
- Step 3: Finished	19.

Index

5. Configuration	20.
A. By Browser	20.
- Step 1: Ready to login	20.
- Step 2: Configure your parameters	21.
- Step 3: Finish and reboot	22.
B. By Setup Tools	23.
- Step 1: Searching the devices	23.
- Step 2: Double click the selected item	23.
- Step 3: Configure and update your parameters	24.
C. By Direct Broadcast Commands	25.
- Command List A	25.
- Command List B	26.
- Command List C	27.
6. Parameter Description	28.
7. Application Notes	34.
A. Description	34.
B. Disable Firewall of Windows XP SP2	34.
- Step 1: Execute "Windows Firewall"	34.
- Step 2: Close the Firewall	35.
C. Make Program exception for Firewall	36.
- Step 1: Choose "Exception"	36.
- Step 2: Add on New Program	37.
- Step 3: Allow "Accept any Computer"	38.
- Step 4: Finished	39.
8. Appendix	40.

Disclaimers

The information in this manual has been carefully checked and is believed to be accurate. Infosystem Technology Corporation, Ltd. assumes no responsibility for any infringements of patents or other rights of third parties, which may result from its use.

Infosystem assumes no responsibility for any inaccuracies that may be contained in this document. Infosystem makes no commitment to update or to keep current the information contained in this manual.

Infosystem reserves the right to make improvements to this document and/or product at any time without notice.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form of or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Infosystem Technology Corporation, Ltd.

Copyright © 2007

Infosystem Technology Corporation, Ltd.

All rights reserved. Printed in Taiwan.

Warranty

All products manufactured by Infosystem are warranted against defective materials for a period of one year from the date of delivery to the original purchaser.

Trademark

The names used for identification only maybe registered trademark of their respective companies.

Product Information

A. Introduction

WM is module-based product and it can provide an ideal solution to customized embedded systems. By embedding WM Products into customized systems, you can easily implement Serial to Ethernet Converting affairs.

WM-112 uses SoC for implementing RS232 to Ethernet functions. It uses the state machine to handle TCP/IP stack and brings the user a lower cost TCP/IP stack with limited functions because of the limited resources.

WM-112 is a small size and low cost module solution. It is easy to implement applications in IA, Factory Automation, Security or any other low data rate data transmission by using it as the coprocessor. It supports ARP, ICMP, TCP, UDP, IP, DHCP-Client and even HTTP protocols. It supports 10/100M speed at Ethernet port and 115.2Kbps on Serial Port. You may use any browsers to set the parameters, or just use the commands in console mode with setup tools. With no doubt, WM-112 will bring you the easiest managements in your applications.

B. Features


- Easy Configuration Setting
 - ✓ *Software Setup Tool for Configuration Setting*
 - ✓ *Use HTTP, IE/Netscape Browser for Setting*
- Good Security Concerned
 - ✓ *Setup Login in Password Protect*
 - ✓ *Access Password Protect*
 - ✓ *Support New Version Firmware Upgradeable*
- Low cost and High Reliability
 - ✓ *Cheap and stable*
 - ✓ *Working 24Hours per day*
- Low Power Consumption
 - ✓ *Less than 1W Power Consumption*
- Support Necessary Network Protocols
 - ✓ *ARP, ICMP, TCP, UDP, IP, DHCP Client, HTTP*
- Support Various Interfaces (Universal Set)
 - ✓ *RJ-45 x 1, 10/100M, Auto MDI/MDIX*
 - ✓ *Serial Port x 1, 115.2Kbps, RTS/CTS H/W flow control*
 - ✓ *RS-232/RS-485/RS-422 Software Configurable*
 - ✧ *Half Duplex for RS485*
 - ✧ *Full Duplex for RS-422*
 - ✧ *5 bits Digital I/O (Modbus/TCP, Port 502)*
- Three Independent Sockets
 - ✓ *Support multi sockets for serial port and Digital I/O port*
 - ✓ *All protocol working independent and concurrently*

C. Applications

- Data collection
- Security Terminals
- Access Control Terminals
- Security Devices
- Time Recorders
- Warehouse Terminals
- Shop floor automation Terminals
- Remote Sensors and Various Meters
- Power monitors
- Power meters
- Environmental monitors
- Temperature monitors
- Data loggers
- Data Acquisitions
- Auto-ID Scanners
- Barcode Scanners
- Magnetic Card Readers

Exterior

A. Top View



B. PIN Assignment

□ 1	TPRX-	IO4	□ 24
□ 2	TPRX+	IO3	□ 23
□ 3	VCC	CTS	□ 22
□ 4	LED_LINK	RTS	□ 21
□ 5	LED_RX	TXD	□ 20
□ 6	LED_TX	RXD	□ 19
□ 7	LED_SYS	IO2	□ 18
□ 8	GND	IO1	□ 17
□ 9	TPTX-	IO0	□ 16
□ 10	TPTX+	/RST	□ 15
□ 11	SHIELD	IO5/RS485	□ 14
□ 12	IO6	ISP/SETUP	□ 13

WM-112 Module

Exterior

C. PIN Descriptions

PIN	Name	Type	Description
1	TPRX-	I	The AUI receive input pairs carries the differential receives input signal from the MAU.
2	TPRX+	I	Same as the Pin 1, it is a positive differential input of the AUI.
3	VCC	P	+5V DC Power
4	LED_LINK	O	Active Low, Active while the UTP cable is plugged and link
5	LED_RX	O	Blinking while receiving a Ethernet Packet.
6	LED_TX	O	Blinking while transmitting a Ethernet Packet.
7	LED_SYS	O	There are three signal states of this LED 1. Blinking Per second while normal operation 2. Blink Fast while power on do self test. 3. Low while error or restored factory default parameter
8	GND	P	GND, DC power
9	TPTX-	O	This is AUI transmit output pair contains the differential line drivers which send Manchester encoded data to the MAU.
10	TPTX+	O	Same as Pin 9, it is the Positive differentials transmit out.
11	SHIELD GND	P	The shield GND.
12	IO6/Hal_Duplex	I/O	Digital I/O or it is a half duplex control of the RS-485
13	ISP/SETUP	I	Active low, will cause System enter into ISP mode while power plugged in and low this pin. Or Enter into Restored factory default parameter mode
14	IO5/RS485	I/O	Digital I/O, or it is a RS-485 or RS-422 function selector.
15	/RST	I	Reset Pin
16	IO0	I/O	Digital I/O
17	IO1	I/O	Digital I/O
18	IO2	I/O	Digital I/O
19	RXD	I	UART Rx data in.
20	TXD	O	UART Tx data in
21	RTS	O	RS232 /RTS
22	CTS	I	RS232 /CTS
23	IO3	I/O	Digital I/O
24	IO4	I/O	Digital I/O

Software Installation

A. Installation

Step 1: Insert the CD and click the button

The Software Installation CD that came with EIO-A-200 will automatically be run after inserting it into the CD-ROM drive. Click the “Ethernet converter Setup Utilities” button will bring the installation page out,




Figure1. Software Install CD Auto-Run Screen Shot

Software Installation

A. Installation

Step 2: Click the Link of the Page

Click the Link of the Page to run the Ethernet Converter Setup Tools Installation Software.




Figure2. Ethernet Converter Setup Tools Page

Software Installation

A. Installation

Step 3: Press Next to Continue




Figure3. Installation Welcome Message

Software Installation

A. Installation

Step 4: Decide the Application Directory




Figure4. Decide the Application Directory

Software Installation

A. Installation

Step 5: Create the Directory if not existent




Figure5. Create Application Directory

Software Installation

A. Installation

Step 6: Create Program's Shortcut




Figure6. Shortcut Creation

Software Installation

A. Installation

Step 7: Decide if Desktop icon needed




Figure7. Desktop Icon Creation

Software Installation

A. Installation

Step 8: Press Install to start installation




Figure8. Review the Installation Settings

Software Installation

A. Installation

Step 9: Process Installations




Figure9. Installing

Software Installation

A. Installation

Step 10: Finish Installation




Figure10. Installation Finished

Software Installation

B. Uninstall

Step 1: Execute Uninstall Program

Uninstall Program is located at the application directory named “Uninstall Ethernet Converter Setup”. Execution of it could let the Ethernet Converter Setup Tools clearly be removed.




Figure11. Decide the Application Directory

Software Installation

B. Uninstall

Step 2: Click “Yes” to process




Figure12. Process Uninstall

Step 3: Finished





Figure12. Process Uninstall

Configuration

A.By Browser

Step 1: Ready to login.



Configuration

A. By Browser

Step 2: Configure your parameters.

Setup - Microsoft Internet Explorer

檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)

← 上一頁 → 搜索 我的最愛 移至 連結 >>

網址(O) http://192.168.1.1/Setup.htm

Converter Setup

Local IP	192.168.1.1
Subnet mask	255.255.255.0
Gateway IP	192.168.1.254
DHCP client	Disable
Remote Host IP	0.0.0.0
Remote Host port	0
SIO Port, Type	9925 TCP Server
SIO BaudRate	9600 N 8 1
SIO Type	RS232
SIO Packets Gap	2 ms
Slave Response Time out	600 ms
Device ID	
Setup password	
Access password	
Multi Sockets Arbitration Time	0 ms

Note: SIO Port 502 is Reserved for the MODBUS/TCP.

Update


完成 網際網路

Configuration

B. By Setup Tools

Step 1: Searching the devices.

Step 2: Double click the selected item.




Configuration

B. By Setup Tools

Step 3:

Configure and update your parameters.



Parameter	Value
IP address	192.168.1.1
Subnet mask	255.255.255.0
Gateway IP address	192.168.1.254
DHCP client	Disable
Host IP address	0.0.0.0
Host socket port	0
Socket port of serial I/O, Type	9925 TCP Server
Serial I/O settings (baud rate, parity, data bits, stop bits)	9600 N 8 1
Type of serial I/O	RS232
SIO InterCharacter Gap	2
Slave Response Time Out	600 ms
Device ID	
Setup password	
Access password	
Multi Socket Arbitration Time Period	0 ms

Note: SIO Port 502 is Reserved for the MODBUS/TCP.

Update Cancel

Configuration

C. By Direct Broadcast Commands

It needs broadcasting to handle all the configurations and it allows users to code their own application software.

- Command List A – User Level –

Command	Description	Notes	
X or x	Purpose	<i>For Broadcast search</i>	
	Syntax	<i>X <magic code></i>	
	Magic code	<i>99.130.83.99</i>	
	Return	<i>AX <MAC>/<IP>/<Device ID></i>	
	Example	Send	<i>X 99.130.83.99</i>
Back		<i>AX 0.128.200.255.251.242/192.168.1.1/1</i>	
G or g	Purpose	<i>Get all the parameters of the WM-112</i>	
	Syntax	<i>G <MAC>/<IP>/<Setup Password></i>	
	Return	<i>All the parameters of the WM-112</i>	
	Example	Send	<i>G 0.128.200.255.251.242/192.168.1.1/123</i>
		Back	<i>CG for cancel</i>
<i>AG<All Messages></i>			

Configuration

C. By Direct Broadcast Commands

User Level: For General Users

Admin Level: For Factory Default Setting

- Command List B – User Level –

Command	Description	Notes	
S	Purpose	Set the parameters of WM-112	
	Syntax	S <MAC>/<IP>/<Password>/<Parameter>/<Value>	
	Return	A for accept	
		C for cancel	
	Example	Send	S 0.128.200.255.251.242/192.168.1.1/123/IP/192.168.1.2
		Back	A or C
R	Purpose	Reboot WM-112	
	Syntax	R <MAC>/<IP>/<Setup Password>	
	Return	AR for accept	
		CR for cancel	
	Example	Send	R 0.128.200.255.251.242/192.168.1.1/123
		Back	AR or CR

Configuration

C. By Direct Broadcast Commands

User Level: For General Users

Admin Level: For Factory Default Setting

- Command List C – Admin Level –

Command	Description	Notes	
M	Purpose	Set MAC of WM-112 then reboot automatically	
	Syntax	M <Old MAC>/<New MAC>/<Factory Password>	
	Return	AM for accept	
		CM for cancel	
	Example	Send	S 0.128.200.255.251.242/0.128.200.255.251.243/123
Back		'A' or 'C'	
I	Purpose	Set IP for Factory settings	
	Syntax	I <MAC>/<New IP>/<Factory Password>	
	Return	AI for accept	
		CI for cancel	
	Example	Send	I 0.128.200.255.251.242/192.168.1.1/123'
Back		AR or CR	

Parameter Description

Parameter	Description
Local IP	The IP address of the WM-112 converter on the TCP/IP network. The default Local IP address is 192.168.1.250. This address should be unique. Ask your network administrator for assistance, if in doubt.
Subnet Mask	Identifying the network class which the WM-112 converter belongs to. The default Subnet mask is: 255.255.255.0 for Class C IP. Ask your network administrator for assistance, if in doubt.
Gateway IP	The IP address of the router. The default Gateway IP address is: 192.168.1.254, Ask your network administrator for assistance, if in doubt.
DHCP Client	If this option is enabled, that means the IP address, Subnet mask and Gateway IP address of the WM-112 converter are set dynamically by the DHCP Server. If the setting cannot be got from the DHCP server successfully, the WM-112 converter will use the last setup parameters for its configuration. The possible reason of this case is that the DHCP server is shutdown or not available. Ask your network administrator for assistance, if in doubt.

Parameter Description

Parameter	Description
SIO Port, Type	<ul style="list-style-type: none"> ➤ The local port number of the WM-112 converter to be contacted by other devices. The default value is 9925. And users need to choose one communication mode for the WS-100 converter. There are four different communication modes can be selected. They are TCP Server, TCP Client, UDP Server and UDP Client. ➤ TCP Server – The WM-112 converter will operate at the Passive or the TCP listen mode to receive TCP connection requests from the remote client device. ➤ TCP Client – The WM-112 converter will operate at the Active or the TCP Active mode to request establishing a TCP connection with the remote server device. ➤ UDP Server – The WM-112 converter will operate at the UDP Server mode to send and receive UDP datagram to/from the remote device.
Socket port of serial I/O, Type	<ul style="list-style-type: none"> ➤ UDP Client – The WM-112 converter will operate at the UDP Client mode to send and receive UDP datagram to/from the remote device specified in Remote Host IP address and Remote Host Port. ➤ NOTE: SIO port number 502 is reserved for the Modbus/TCP protocol. When user connects the serial Modbus device running in Modbus/RTU Slave mode, the WM-112 converter can receive connection requests from Modbus/TCP Master device. Also when user connects the serial Modbus device running in Modbus/RTU Master mode, the WM-112 converter can connect to Modbus/TCP Slave device.

Parameter Description

Parameter	Description
DIO Port, Type	Reserved
SIO Baud Rate	The serial parameter settings: <ul style="list-style-type: none"> ➤ Baud Rate: 300 bps to 115200 ➤ Parity: None, Even, or odd ➤ Data Bits: 7, or 8 ➤ Stop Bit: 1, or 2
Socket I/O settings(baud rate, parity, data bits, stop bits)	
SIO Type	The serial interface types: <ul style="list-style-type: none"> ➤ RS232 ➤ RS232 with RTS/CTS control ➤ RS232 with RTS/CTS/DSR/DTR control ➤ RS485 half duplex mode ➤ RS422 full duplex mode
Type of serial I/O	
SIO Packets Gap	In some cases, for example, if the Modbus/RTU serial protocol is used, the completion of the message packet in the input buffer is determined by a character-to-character timeout. The SIO Packets Gap of WM-112 defines this timeout period.
SIO Inter-Character Gap	

Parameter Description

Parameter	Description
Remote Host IP	If the WM-112 converter is used in TCP client mode or UDP client mode, the Remote Host IP address must be specified to establish the connection with the designated HOST (server) only.
Remote Host Port	If the WM-112 converter is used in TCP client mode or UDP client mode, the Host Port No. must be specified. This is the port which the Remote Host IP listens for incoming data.
Slave Response Time Out	Expected Time Out for the response of slave machines
Device ID	Just Device ID for WM-112 devices

Parameter Description

Parameter	Description
TCP Link Time Out	When this option is enabled, the TCP communication will be disconnected by the WM-112 converter if there is no further TCP activity within the given timeout value.
Command Port	The WM-112 converter supports the command mode, which user can use to setup the parameters or get the information of the converter with UDP protocol from the remote host. The default Command Port number is 65535. The command port of the WM-112 converter should be set correctly while using the command mode. Please refer to appendix 1 for further

Parameter Description

Parameter	Description
Setup password	This password protects the Setup window of the WM-112 converter from unauthorized entry. To erase an existing password, just leave the Setup password text box blank.
Access password	If this password is configured, the remote host needs to send this access password one second periodically to the Check Status Port of the WM-112 converter; otherwise the data transfer request will not be accepted by the WM-112 converter. To erase an existing password, just leave the Access password text box blank.
Multi Sockets Arbitration Time Period	Arbitration Time period between multi sockets. Default is 0ms for single socket. And 20 ms is suggested when using multi sockets.

Application Notes

A. Description:

Firewall will make the program off normal, so one might choose the following solutions to Firewall program, “Disable” or “Exception”.

B. Disable Firewall of Windows XP SP2.

Step 1: Execute "Windows Firewall"

Execute “Windows Firewall” in Control Panel.




Application Notes

B. Disable Firewall of Windows XP SP2.

Step 2: Close the Firewall

Choose “Close” to close firewall.




Application Notes

C. Make Program exception for Firewall

Step 1: Choose "Exception"

Choose "Exception" in Firewall Program.
And add on new program of Setup Tools.



Application Notes

C. Make Program exception for Firewall

Step 2: Add on New Program and Selection
Choose “Setup Tools” to make it as an
exception.




Application Notes

C. Make Program exception for Firewall

Step 3: Allow "Accept Any Computer"


Allow "Accept Any Computer" to finish exception.



Application Notes


C. Make Program exception for Firewall

Step 4: Finished Finish Exception.



Appendix

A. Application Circuit



The logo for Infosystem, featuring the word "Infosystem" in a white serif font with a registered trademark symbol (®) to its upper right. The text is centered within a rectangular background that has a vertical gradient from red on the left to orange on the right.

Infosystem®

Copyright © 2007

Infosystem Technology Corporation, Ltd.

No. 45, Lane 167, Dongnan St.

Hsinchu, Taiwan 300, R.O.C.

TEL: +886-3-562-7187

FAX: +886-3-561-1435

Service E-mail: services@infosystem.com.tw

Web page URL: <http://www.infosystem.com.tw>